

## GRYPHON™ GPS4400 SYMBOLOGIES

UPC-A Disable



UPC-A Enable



UPC-E Disable



UPC-E Enable



EAN-13 Disable



EAN-13 Enable



EAN-8 Disable



EAN-8 Enable



Code 39 Disable



Code 39 Enable



Disable Code 128



Enable Code 128



Disable Interleaved 2 of 5



Enable Interleaved 2 of 5



Disable Follet 2 of 5



Enable Follet 2 of 5



Disable Standard 2 of 5



Enable Standard 2 of 5



Disable Industrial 2 of 5



Enable Industrial 2 of 5



Disable Codabar



Enable Codabar



Disable Code 11



Enable Code 11



Disable GS1 Databar Omni Directional



Enable GS1 Databar Omni Directional



Disable GS1 Databar Expanded



Enable GS1 Databar Expanded



Disable GS1 Databar Limited



Enable GS1 Databar Limited



Disable Code 93



Enable Code 93



Disable MSI



Enable MSI



Disable Plessey



Enable Plessey



Disable Datamatrix



Enable Datamatrix



Disable Aztec



Enable Aztec



Disable QR Code



Enable QR Code



Disable Micro QR



Enable Micro QR



Disable Maxi Code



Enable Maxi Code



Disable PDF 417



Enable PDF 417



Disable Micro PDF



Enable Micro PDF

