

CASE CONVERSION

Programming codes are for the following products:

- Gryphon™ GBT44X0
- Gryphon™ GM44X0
- Gryphon™ GD4400
- Gryphon™ GFS4400

Case Conversion = Disable



Case Conversion = Convert to Upper Case



Case Conversion = Convert to Lower

