


ENABLE-DISABLE CELLPHONE MODE

Programming codes are for the following products:

- Magellan™ 800i
- Magellan™ 1000i
- Magellan™ 1100i
- Magellan™ 1400i
- Magellan™ 3200
- Magellan™ 3300

Cell Phone Mode = Disable



Cell Phone Mode = Enable

