

## MAGELLAN™ 9800I REMOTE DISPLAY OPTIONS

Programming codes are for the following products:

- Magellan™ 9800i

Enter Programming Mode



Remote Display = Enable



Remote Display = Disable

