

## SCAN MODE OPTIONS

Programming codes are for the following products:

- Gryphon™ GD4100
- Gryphon™ GM4100
- Gryphon™ GBT4100
- Gryphon™ GD4300
- Quickscan™ QD2100
- Quickscan™ QW2100
- PowerScan™ PD7100
- PowerScan™ PBT7100
- Touch™ TD1100

Scan Mode = Trigger Single (Default)



Scan Mode = Always on



Scan Mode = Stand

