

## ENABLE / DISABLE BATCH MODE

Programming codes are for the following products:

- Gryphon™ GBT44X0
- Gryphon™ GM44X0
- Gryphon™ GBT4100
- Gryphon™ GM4100

Scan one of the barcodes below to either enable or disable the batch mode.

Batch Mode Disable



Batch Mode Enable



In the batch mode, scan one of the codes below to either send the batch or erase the batch

Send Batch Data



Erase Batch Data

