

CASE CONVERSION OPTIONS

Programming codes are for the following products:

- Gryphon™ GD4100
- Gryphon™ GM4100
- Gryphon™ GBT4100
- Gryphon™ GD4300
- Quickscan™ QD2100
- Quickscan™ QW2100
- PowerScan™ PD7100
- PowerScan™ PBT7100
- Touch™ TD1100

Case Conversion = Disable



Case Conversion = Convert to Upper



Case Conversion = Convert to Lower

