

## UPC / EAN OPTIONS

Programming codes are for the following products:

- Gryphon™ GD4100
- Gryphon™ GM4100
- Gryphon™ GBT4100
- Gryphon™ GD4300
- Quickscan™ QD2100
- Quickscan™ QW2100
- PowerScan™ PD7100
- PowerScan™ PBT7100
- Touch™ TD1100

### UPC-A Options

UPC A = Disable



UPC A = Enable



UPC A Check Digit = Disable



UPC A Check Digit = Enable



UPC A Expand to EAN 13 = Disable



UPC A Expand to EAN 13 = Enable



UPC A Number System Character = Disable



UPC A Number System Character = Enable



## UPC-E Options

UPC E = Disable



UPC E = Enable



UPC E Check Digit = Disable



UPC E Check Digit = Enable



UPC E Expand to EAN 13 = Disable



UPC E Expand to EAN 13 = Enable



UPC E Expand to UPC A = Disable



UPC E Expand to UPC A = Enable



UPC E Number System Character = Disable



UPC E Number System Character = Enable



## EAN-13 Options

EAN 13 = Disable



EAN 13 = Enable



EAN 13 Check Digit = Disable



EAN 13 Check Digit = Enable



EAN 13 Number System Character = Disable



EAN 13 Number System Character = Enable



## EAN 8 Options

EAN 8 = Disable



EAN 8 = Enable



EAN 8 Check Character = Disable



EAN 8 Check Character = Enable



EAN 8 Expand to EAN-13 = Disable



EAN 8 Expand to EAN-13 = Enable

