


MAGELLAN™ REMOTE DISPLAY

Programming codes are for the following products:

- Magellan™ 8100
- Magellan™ 8200
- Magellan™ 8300
- Magellan™ 8400
- Magellan™ 8500
- Magellan™ 8500XT
- Magellan™ 8500XTS
- Magellan™ 9500

Scan this barcode to disable the Remote Scale Display; the Switch Label is built in.

Remote Display Disable



Scan this barcode to enable the Remote Scale Display; the Switch Label is built in.

Remote Display Enable

