

GRYPHON™ GPS4400 CONNECTING TO A VERIFONE TOPAZ

RS-232 Interface



Enter Configuration



Global Suffix = CRLF / Label ID = Enable / PDF 417 Label ID = X / Expand UPC-E to UPC-A = Enable



Exit Configuration

