

## MAGELLAN™ 9800I TDR OPTIONS

Programming codes are for MGL 9800i

Enter Programming Mode



Enable TDR



Disable TDR

