

Inter-Code Delay

Please Note: Inter-Code Delay only works on the USB Keyboard interface type.

Programming codes are for the following products:

- Gryphon™ Imager (Desk, Mobile and BT)
- Gryphon™ Laser (Desk, Mobile and BT)
- Quicksan™ Imager
- Powerscan™ D7100 or BT7100

Inter-Code = No Delay



Inter-Code = 1 Sec.



Inter-Code = 2 Sec.



Inter-Code = 3 Sec.



Inter-Code = 4 Sec.



Inter-Code = 5 Sec.



Inter-Code = 6 Sec.



Inter-Code = 7 Sec.



Inter-Code = 8 Sec.



Inter-Code = 9 Sec.



Inter-Code = 10 Sec.

