RF DEVICE SETUP FOR STAR★Modem™


SETUP FOR STAND ALONE MODE

The following procedure allows configuring an RF Device to communicate with STAR★Modem™ in Stand Alone Mode:

1. **Restore RF Device Default**



2. **Enter Configuration**



ONLY FOR DRAGON™ M

3. **Set Date**



+

six digits for Day, Month and Year (DDMMYY).

4. **Set Time**




+

four digits for Hours and Minutes (HHMM).

Set RF Device Address

5.



+

four digits from the Numeric Table in the range **0000-1999**.

All RF Devices must have different addresses.

STAR★Modem™ Address

6.



read the code above and the four-digit address of the STAR★Modem™.

Exit and Save Configuration

7.



SETUP FOR STAR-SYSTEM™ MODE

The following procedure allows configuring an RF Device to communicate with STAR★Modem™ in STAR-System™ Mode:

1. **Restore RF Device Default**



2. **Enter Configuration**



ONLY FOR DRAGON™ M

3. **Set Date**



+

six digits for Day, Month and Year (DDMMYY).


4. **Set Time**



+

four digits for Hours and Minutes (HHMM).

5. **Set RF Device Address**



+

four digits from the Numeric Table in the range **0000-1999**.

All RF Devices must have different addresses.

STAR-Modem™ Address

6.



read the code above and the four-digit address of the STAR-Modem™

Exit and Save Configuration

7.



NUMERIC TABLE



0



1



2



3



4



5



6



7



8



9