


STS320 AND MATRIX 320 ATS ACCESSORIES


QUICK REFERENCE GUIDE




Covers

©2021 Datalogic S.p.A. and/or its affiliates
• All rights reserved • Without limiting the rights under copyright, no part of this documentation may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means, or for any purpose, without the express written permission of Datalogic S.p.A. and/or its affiliates • Datalogic and the Datalogic logo are registered trademarks of Datalogic S.p.A. in many countries, including the U.S. and the E.U.













SUPPORT THROUGH THE WEBSITE

Datalogic provides several services as well as technical support through its website.
Log on to www.datalogic.com.
For quick access, from the home page click on the search icon , and type in the name of the product you're looking for. This allows you access to download Data Sheets, Manuals, Software & Utilities, and Drawings.
Hover over the Support & Service menu for access to Services and Technical Support.

www.datalogic.com



821007461 (Rev. B) May 2021

 <p>Please read the instructions contained herein carefully to prevent damage to the reader and its components.</p>	 <p>Please read the instructions contained herein carefully to prevent damage to the reader and its components.</p>	 <p>Please read the instructions contained herein carefully to prevent damage to the reader and its components.</p>	 <p>Please read the instructions contained herein carefully to prevent damage to the reader and its components.</p>
 <p>Please read the instructions contained herein carefully to prevent damage to the reader and its components.</p>	 <p>Please read the instructions contained herein carefully to prevent damage to the reader and its components.</p>	 <p>Please read the instructions contained herein carefully to prevent damage to the reader and its components.</p>	 <p>Please read the instructions contained herein carefully to prevent damage to the reader and its components.</p>
 <p>Please read the instructions contained herein carefully to prevent damage to the reader and its components.</p>	 <p>Please read the instructions contained herein carefully to prevent damage to the reader and its components.</p>	 <p>Please read the instructions contained herein carefully to prevent damage to the reader and its components.</p>	 <p>Please read the instructions contained herein carefully to prevent damage to the reader and its components.</p>
 <p>Please read the instructions contained herein carefully to prevent damage to the reader and its components.</p>	 <p>Please read the instructions contained herein carefully to prevent damage to the reader and its components.</p>	 <p>Please read the instructions contained herein carefully to prevent damage to the reader and its components.</p>	 <p>Please read the instructions contained herein carefully to prevent damage to the reader and its components.</p>

Covers LT 14 and 36 LEDs



Description	Order number
Cover LT 14L STS320/ATS320	93ACC0323
Cover LT 36L STS320/ATS320	93ACC0324

COVER REPLACEMENT



CAUTION: The reader must be disconnected from the power supply during the cover replacement procedure.



CAUTION: Make sure to operate in a dust-free environment during the cover replacement procedure.


1. Unscrew the four screws using a 2.5 mm Allen wrench.
2. Remove the cover. The cover will remain attached to the body because of the gasket. To unmount it properly, it is recommended to gently lever the cover from its corners using a flat blade screwdriver between the cover and the body of the reader. See Fig. 1 and Fig. 3.




CAUTION: Do not attempt to force the clip locks open (see Fig. 2).



CAUTION: When removing the cover to replace it, the Poron filter frame might stick to the removed window. Make sure to reassemble it.



Poron filter frame
(14 LEDs illuminator model)



Poron filter frame
(36 LEDs illuminator model)



CAUTION: All cover accessories are supplied with a mounted gasket. When replacing the cover, the gasket may remain attached to the base. Make sure to remove the old gasket, since the new cover is already supplied with its own gasket.

3. Make sure the new cover is free of dust, dirt and fingerprints. If necessary, wipe it clean using soft material and alcohol. Avoid any abrasive substances.



CAUTION: The cover has a predefined mounting direction (see Fig. 4 and Fig. 5). For the 14 LEDs model (Fig. 4), make sure to align the identification grooves to the right side. For the 36 LEDs model (Fig. 5), the illuminator has one pin different from the other three: make sure to align this special pin with the correspondent cover seat.

4. Place the new cover on the reader and press the cover frame edges.



CAUTION: To avoid damage, do not press on the window.

5. Insert the four screws and loosely tighten them in a clockwise direction.
6. Finally tighten the screws to a torque of 0.8 N m.




Fig. 1 - Removing the cover (14 LEDs model)




Fig. 2 - Do not force the clip locks open




Fig. 3 - Removing the cover (36 LEDs model)




Fig. 4 - Aligning the cover (14 LEDs model)




Fig. 5 - Aligning the cover (36 LEDs model)