

Datalogic S.r.l.
Via San Vitalino 13
40012 Calderara di Reno (BO)
Italy
Tel. +39 051 3147011
Fax +39 051 3147205

©2021-2022 Datalogic S.p.A. and/or its affiliates

All rights reserved. Without limiting the rights under copyright, no part of this documentation may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means, or for any purpose, without the express written permission of Datalogic S.p.A. and/or its affiliates.

Owners of Datalogic products are hereby granted a non-exclusive, revocable license to reproduce and transmit this documentation for the purchaser's own internal business purposes. Purchaser shall not remove or alter any proprietary notices, including copyright notices, contained in this documentation and shall ensure that all notices appear on any reproductions of the documentation.

Electronic versions of this document may be downloaded from the Datalogic website (www.datalogic.com). If you visit our website and would like to make comments or suggestions about this or other Datalogic publications, please let us know via the "Contact" page.

Disclaimer

Datalogic has taken reasonable measures to provide information in this manual that is complete and accurate, however, Datalogic shall not be liable for technical or editorial errors or omissions contained herein, nor for incidental or consequential damages resulting from the use of this material. Datalogic reserves the right to change any specification at any time without prior notice.

Trademarks

Datalogic and the Datalogic logo are registered trademarks of Datalogic S.p.A. in many countries, including the U.S.A. and the E.U.
Matrix 320, STS320, ID-NET, DL.CODE, and X-PRESS are trademarks of Datalogic S.p.A. and/or its affiliates. All other brand and product names may be trademarks of their respective owners.


Download the STS320 Product Reference Guide by reading the QR code here or see the paragraph below.



SUPPORT THROUGH THE WEBSITE

Datalogic provides several services as well as technical support through its website.

Log on to www.datalogic.com.

For quick access, from the home page click on the search icon , and type in the name of the product you're looking for. This allows you access to download Data Sheets, Manuals, Software & Utilities, and Drawings.

Hover over the Support & Service menu for access to Services and Technical Support.

PATENTS

See www.patents.datalogic.com for patent list.

This product is covered by one or more of the following patents:

Utility patents: EP1172756B1, EP2517148B1, EP2616988B1, EP2649555B1, EP3016028B1, EP3092597B1, IT1404187, JP5947819B2, US10229301, US6808114, US6877664, US6997385, US7387246, US7433590, US7433590, US8245926, US8888003, US8915443, US9122939, US9349047, US9361503, US9798948, US10133895, US10229301, US10540532, ZL200980163411.X, ZL201080071124.9, ZL201180044793.1, ZL201280010789.8

MATRIX 320™ ATS

QUICK REFERENCE GUIDE






Image Based Industrial Reader

©2021-2022 Datalogic S.p.A. and/or its affiliates

• All rights reserved • Without limiting the rights under copyright, no part of this documentation may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means, or for any purpose, without the express written permission of Datalogic S.p.A. and/or its affiliates • Datalogic and the Datalogic logo are registered trademarks of Datalogic S.p.A. in many countries, including the U.S. and the E.U.


www.datalogic.com




821007541 (Rev. B) March 2022

Matrix 320 ATS comes with two different illuminators: with 14 LEDs and with 36 LEDs.

Matrix 320 ATS with 14 LEDs illuminator




1	Lens Cover
2	HMI X-PRESS Interface
3	Green Spot
4	Red Spot
5	Aiming System Laser Pointers
6	Internal Illuminator
7	Lens
8	360° Feedback
9	Bracket Mounting Holes (4)
10	Ethernet Connection LED
11	Power - COM - I/O Connector
12	Ethernet Connector
13	Power On LED
14	Device Class and Warning Labels
15	Avoid Laser Exit Point Label





Connector block rotates to 0° and 90° position

Matrix 320 ATS with 36 LEDs illuminator




1	HMI X-PRESS Interface
2	Lens Cover
3	Lens
4	Red Spot
5	Green Spot
6	Internal Illuminator
7	Aiming System Laser Pointers
8	360° Feedback
9	Bracket Mounting Holes (4)
10	Ethernet Connector
11	Power - COM - I/O Connector
12	Ethernet Connection LED
13	Power On LED
14	Device Class and Warning Labels
15	Avoid Laser Exit Point Label



M12 17-pole male Power, COM, and I/O connector

Pin	Name	Description
1	Vdc	Power supply input voltage +
2	GND	Power supply input voltage -
Connector case	CHASSIS	Connector case provides electrical connection to the chassis
6	I1A	External Trigger A (polarity insensitive)
5	I1B	External Trigger B (polarity insensitive)
13	I2A	Input 2 A (polarity insensitive)
3	I2B	Input 2 B (polarity insensitive)
9	O1	Output 1 * (NPN, PNP or PP short circuit protected and software programmable)
8	O2	Output 2 *
16	O3	Output 3
14	RX	Auxiliary RS232 RX
4	TX	Auxiliary RS232 TX
7	ID+	ID-NET network data +
15	ID-	ID-NET network data -
		RS232 RS422 Full-Duplex
17	Main Interface (SW selectable)	TX TX+
11		RX RX+ **
12		- TX-
10		- RX- **

* Output 1 and Output 2 are opto-coupled when using a CBX.
** Do not leave floating. See Product Reference Guide for connection details.



M12 X-Coded female Ethernet Network connector

Pin	Name	Description
1	DA+	Bidirectional data DA+
2	DA-	Bidirectional data DA-
3	DB+	Bidirectional data DB+
4	DB-	Bidirectional data DB-
5	DD+	Bidirectional data DD+
6	DD-	Bidirectional data DD-
7	DC-	Bidirectional data DC-
8	DC+	Bidirectional data DC+

INSTALLATION PROCEDURE


- Physically mount the Matrix 320 ATS reader.
- Make the necessary electrical connections.
- Configure the reader using the X-PRESS interface (simple configuration) or the DL.CODE software configuration program (complete configuration).

HMI X-PRESS™ INTERFACE

In normal operating mode the colors and meaning of the five LEDs are illustrated in the following table:

READY (green)	indicates the device is ready to operate.
GOOD (green)	confirms successful reading.
TRIGGER (yellow)	indicates the status of the reading phase.
COM (yellow)	indicates active communication on main serial port.
STATUS (red)	indicates NO READ result.

During the reader startup (reset or restart phase), all the LEDs blink for one second.



The single push button gives immediate access to the following relevant functions:

- Test Mode with bar graph visualization to check static reading performance.
- Aim/Autofocus turns on the laser LED to aim the reader at the target. The target should be placed 16 mm (14 LEDs model) or 30 mm (36 LEDs model) upwards and centered horizontally with respect to the aiming pattern (cross).
- Setup to self-optimize and auto-configure photometry parameters.
- Learn to self-detect and auto-configure for reading an unknown barcode (by type and length). Only one symbology can be saved using this method. Performing Autolearn on a second symbology will overwrite the first one.

TECHNICAL SPECIFICATIONS

Electrical Features	
Power	
Supply Voltage	24 Vdc ± 10%
Peak Supply Current	1 A max.
Average Supply Current	Matrix 320 ATS-0xx/-2xx: 0.42 A Matrix 320 ATS-1xx: 0.62 A
Communication interfaces	
Main: RS232, RS422 Full-Du-plex	2400 to 115200 bit/s
Auxiliary: RS232	2400 to 115200 bit/s
ID-NET	
Ethernet (Built-in) supported application protocols	10/100/1000 Mbit/s TCP/IP, UDP, FTP, EtherNet/IP, Modbus TCP, PROFINET-IO
Inputs	
Input 1 (External Trigger) and Input 2	Opto-coupled and polarity insensitive
Max. Voltage	30 Vdc
Max. Input Current	10 mA
Outputs ¹	
Output 1, 2 and 3	NPN, PNP, or PP short circuit protected
V _{OUT} (I _{LOAD} = 0 mA) max.	24 Vdc
V _{OUT} (I _{LOAD} = 100 mA) max.	3 Vdc
I _{LOAD} max.	100mA

1 When connected to the CBX connection boxes, the electrical features for Output 1 and 2 become the following:
Opto-coupled, V_{CE} = 30 Vdc max.; I_{CE} = 40 mA continuous max.; 130 mA pulsed max.; V_{CE saturation} = 1 Vdc max. @ 10 mA; P_D = 90 mW max. @ 50 °C ambient temperature.

Mounting Distance							
Model	Code Resolution	Reading Width @ min. distance	DOF	Min. Reading Distance	Max. Reading Distance	Focus Distance	Vertical FOV @ min. distance
	mm (mils)	mm (in)	mm (in)	mm (in)	mm (in)	mm (in)	mm (in)
Matrix 320 ATS-000	0.30 (12)	359 (14.13)	250 (9.84)	830 (32.68)	1080 (42.52)	940 (37.01)	202 (7.95)
Matrix 320 ATS-010	0.25 (10)	270 (10.63)		620 (24.41)	870 (34.25)	730 (28.74)	152 (5.98)
Matrix 320 ATS-100	0.35 (14)	375 (14.76)	400 (15.75)	850 (33.46)	1250 (49.21)	1000 (39.37)	211 (8.31)
Matrix 320 ATS-110	0.25 (10)	258 (10.16)		830 (32.68)	1230 (48.43)	970 (38.19)	145 (5.71)
Matrix 320 ATS-200	0.30 (12)	300 (11.81)	170 (6.69)	280 (11.02)	450 (17.72)	330 (12.99)	157 (6.18)

Environmental Features	
Operating temperature ²	-10 to 50 °C (14 to 122 °F)
Storage temperature	-20 to 70 °C (-4 to 158 °F)
Max. humidity	90% non condensing
Vibration resistance EN 60068-2-6	14 mm @ 2 to 10 Hz; 1.5 mm @ 13 to 55 Hz; 2 g @ 70 to 500 Hz; 2 hours on each axis
Bump resistance EN 60068-2-29	30 g; 6 ms; 5000 shocks on each axis
Shock resistance EN 60068-2-27	30 g; 11 ms; 3 shocks on each axis
Protection class ³ EN 60529	IP65 and IP67
Sulfur Gas Resistance	Available for all models according to ISO EN 60068-2-43

Physical Features		
	Matrix 320 ATS with 14 LEDs illuminator	Matrix 320 ATS with 36 LEDs illuminator
Dimensions	H x W x L 110 x 56 x 55.5 mm (4.3 x 2.2 x 2.1 in)	H x W x L 115.5 x 69.25 x 126.6 mm (4.6 x 2.7 x 5.0 in)
Weight (with lens and internal illuminator)	380 g (13.4 oz)	640 g (22.6 oz)
Material	Aluminum	

Software Features	
Readable Code Symbologies	
Readable Symbologies	1D Codes: all standard 1 dimensional symbologies. 2D Codes: Data Matrix, QR Code, Micro QR, MAXI-CODE, Aztec, Dot code. Postal Codes: Australia Post, Royal Mail, Kix code, Japan Post, PLANET, POSTNET (+BB), Intelligent Mail, Swedish Post and many more.
Operating Mode	Continuous, One Shot, Phase Mode, PackTrack
Configuration Methods	X-PRESS Human Machine Interface. Windows-based DL.CODE (Ethernet / Serial interface). Serial Host Mode Programming sequences.
Parameter Storage	Permanent memory (Flash)

Code Quality Metrics	
Standard	Supported Symbologies
ISO/IEC 16022 (always enabled)	Data Matrix ECC 200
ISO/IEC 18004 (always enabled)	QR Code
AIM DPM	Data Matrix ECC 200, QR Code
ISO/IEC 15416	Code 128, Code 39, Interleaved 2 of 5, Codabar, Code 93, EAN-8-13, UPC-A/E

2 High ambient temperature applications should use metal mounting brackets and the heat sink provided in the package for heat dissipation.

3 When correctly connected to IP67 cables with seals.

Optical Features		
	Matrix 320 ATS with 14 LEDs illuminator	Matrix 320 ATS with 36 LEDs illuminator
Image Sensor	CMOS	
Image Format	2.0 Mpixel (1920 x 1080)	
Frame Rate	60 frames/s	
Pitch	± 35°	
Tilt	0° - 360°	
LED Safety	according to EN 62471	
Lighting System	Internal illuminator (14 or 36 LEDs)	
Illumination	Internal illuminators with blue lights	
Aiming System	Laser cross red projection aiming	

User Interface	
LED indicators	Power, Ready, Good; Trigger; Com, Status, (Ethernet Network); Good Read (Green Spot)
Keypad button	Configurable via DL.CODE

COMPLIANCE

General

For installation, use and maintenance it is not necessary to open the reader. Only connect Ethernet and dataport connections to a network which has routing only within the plant or building and no routing outside the plant or building.

Power Supply

ATTENTION: READ THIS INFORMATION BEFORE INSTALLING THE PRODUCT
The unit is intended to be powered by an external power supply ES1, PS3 according to IEC 62368-1:2014.

EMC Compliance

- In order to meet the EMC requirements:
- connect reader chassis to the plant earth ground by means of a flat copper braid shorter than 100 mm;
 - for CBX connections, connect pin "Earth" to a good Earth Ground;
 - for direct connections, connect your cable shield to the locking ring nut of the connector.

CE Compliance

CE marking states the compliance of the product with essential requirements listed in the applicable European directive. Since the directives and applicable standards are subject to continuous updates, and since Datalogic promptly adopts these updates, therefore the EU declaration of conformity is a living document. The EU declaration of conformity is available for competent authorities and customers through Datalogic commercial reference contacts. Since April 20th, 2016 the main European directives applicable to Datalogic products require inclusion of an adequate analysis and assessment of the risk(s). This evaluation was carried out in relation to the applicable points of the standards listed in the Declaration of Conformity. Datalogic products are mainly designed for integration purposes into more complex systems. For this reason it is under the responsibility of the system integrator to do a new risk assessment regarding the final installation.
Warning: this is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

LED Safety

For all Datalogic Matrix 320 compatible internal illuminators, LED emission is classified into Risk Group 1 according to EN 62471:2010.

Laser Safety

This product conforms to the applicable requirements of IEC 60825-1 and complies with 21 CFR 1040.10 except for deviations pursuant to Laser Notice N° 56, date May 8, 2019. This product is classified as a Class 2 laser product according to IEC 60825-1 regulations.

CAUTION: Use of controls or adjustments or performance of procedures other than those specified herein may result in exposure to hazardous visible laser light.

Disconnect the power supply when opening the device during maintenance or installation to avoid exposure to hazardous laser light. The laser beam can be switched on or off through a software command.

The following warning label content is applied to each of the laser equipped products indicated on the opposite page.



Produit(s) conforme selon 21CFR 1040.10 sauf des dérogations relatives à la Laser Notice N° 56, data Mai 8, 2019.

Dans le paquet il y a l'étiquette(s) pour les pays où le texte d'avertissement en français est obligatoire. Le(s) mettre sur le produit à la place de la version anglaise.



WARRANTY

Datalogic warrants that the Products shall be free from defects in materials and workmanship under normal and proper use during the Warranty Period. Products are sold on the basis of specifications applicable at the time of manufacture and Datalogic has no obligation to modify or update Products once sold. The Warranty Period shall be **two years** from the date of shipment by Datalogic, unless otherwise agreed in an applicable writing by Datalogic. Datalogic will not be liable under the warranty if the Product has been exposed or subjected to any: (1) maintenance, repair, installation, handling, packaging, transportation, storage, operation or use that is improper or otherwise not in compliance with Datalogic's instruction; (2) Product alteration, modification or repair by anyone other than Datalogic or those specifically authorized by Datalogic; (3) accident, contamination, foreign object damage, abuse, neglect or negligence after shipment to Buyer; (4) damage caused by failure of a Datalogic-supplied product not under warranty or by any hardware or software not supplied by Datalogic; (5) any device on which the warranty void seal has been altered, tampered with, or is missing; (6) any defect or damage caused by natural or man-made disaster such as but not limited to fire, water damage, floods, other natural disasters, vandalism or abusive events that would cause internal and external component damage or destruction of the whole unit, consumable items; (7) use of counterfeit or replacement parts that are neither manufactured nor approved by Datalogic for use in Datalogic-manufactured Products; (8) any damage or malfunctioning caused by non-restoring action as for example firmware or software upgrades, software or hardware reconfigurations etc.; (9) loss of data; (10) any consumable or equivalent (e.g. cables, power supply, batteries, etc.); or (11) any device on which the serial number is missing or not recognizable.
THE DATALOGIC WARRANTIES ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, WHETHER WRITTEN, EXPRESS, IMPLIED, STATUTORY OR OTHERWISE, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR PARTICULAR PURPOSE. DATALOGIC SHALL NOT BE LIABLE FOR ANY DAMAGES SUSTAINED BY BUYER ARISING FROM DELAYS IN THE REPLACEMENT OR REPAIR OF PRODUCTS UNDER THE ABOVE. THE REMEDY SET FORTH IN THE WARRANTY STATEMENT IS THE BUYER'S SOLE AND EXCLUSIVE REMEDY FOR WARRANTY CLAIMS. NO EXTENSION OF THIS WARRANTY WILL BE BINDING UPON DATALOGIC UNLESS SET FORTH IN WRITING AND SIGNED BY DATALOGIC'S AUTHORIZED REPRESENTATIVE. DATALOGIC'S LIABILITY FOR DAMAGES ON ACCOUNT OF A CLAIMED DEFECT IN ANY PRODUCT DELIVERED BY DATALOGIC SHALL IN NO EVENT EXCEED THE PURCHASE PRICE OF THE PRODUCT ON WHICH THE CLAIM IS BASED. DATALOGIC SHALL NOT BE LIABLE FOR DAMAGES RELATING TO ANY INSTRUMENT, EQUIPMENT, OR APPARATUS WITH WHICH THE PRODUCT SOLD UNDER THIS AGREEMENT IS USED. Further details on warranty coverage, rights and conditions are addressed under and regulated by the Terms and Conditions of Sales of Datalogic available at https://www.datalogic.com/terms_conditions_sales.